

RETOUCH CREAM



WHITE



BLACK

30ml

Libéron Retouch Cream is a soft creamy wax for rubbing into damaged areas to disguise dents, chips, scratches, and for restoring colour. Ideal for filling mitre joints, pin holes on frames or for furniture restoration, it dries hard and all colours are intermixable.

- **Restores colour and disguises dents and chips**
- **Ideal for filling mitre joints and pin holes on frames or furniture**

PREPARATION

Ensure surface is clean, dry and free from dust.

APPLICATION

Apply to the damaged surface with a cloth. Gently remove any excess with a cloth. Allow to dry for a minimum of 20 minutes, longer, if possible, then buff lightly with a lint-free cotton cloth.

Tools can be cleaned with white spirit. If the product dries out, it can be revived by gently warming and adding white spirit.

CAUTION: Risk of self-combustion. Wet with water any textiles or tools soiled with the product and dispose of them in a tightly closed container.

Remove as much of the product as possible from the tools after use. Do not dispose of residues and washing water/solvents in the sink, toilet, sewer, bin, etc., in order to avoid discharge into the environment.



Min. 20 mins



Cloth

This product should be used in accordance with the manufacturer's instructions. Recommendations are for guidance only since conditions of use are completely beyond our control. For technical or practical information on this or other Libéron products please contact Libéron Technical Services on 01797 367555.

This notice is intended to provide information. The information is based on our current knowledge and experience based on conditions of use that comply with the standards or DTU in force. Given the multiplicity of factors that can influence the use of our products, they cannot exempt the user from his own experiences. No legal warranty can be derived from our information. This data sheet supersedes all previous editions.